

Brief description of the Frankenslot Speedflow Controller



Poti description

Left potentiometer (start / gas) = path until first reaction occurs

Middle Poti (Max) = To the right for maximum speed

Right potentiometer (vote) = vote on the route

basic setting

Poti vote all the way to the right. Then set the maximum speed: To do this, press the trigger fully and set the middle potentiometer so that the maximum speed is currently applied.

Then set the minimum: Set so that it does not start in the rest position.

Check: Vote for another stop, it should still not start now (otherwise readjust minimum)

Fine tune

By changing the tuning, the control behavior can be adapted to the route.

For routes that require sensitive control in the low speed range: turn the tuning counterclockwise.

For routes that require fine control in the high speed range: turn the clockwise.

Thus, the curvature of the characteristic curve on the route can be adapted to personal taste.

Buy

The product can be purchased [here](#)!

From:

<https://wiki.frankenslot.de/> - **Frankenslot Wiki**

Permanent link:

https://wiki.frankenslot.de/en/anleitung/speedflow_controller_d132_124

Last update: **2020/06/01 04:14**

